ZyXEL G-200

(Hardware Revision v2)

802.11g Wireless USB Adapter

Quick Start Guide

Version 2.0

2/2006

Important Information

Federal Communications Commission (FCC) Interference Statement

The 802.11g Wireless LAN Adapter has been tested to the FCC exposure requirements (Specific Absorption Rate).

The equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment, under 47 CFR 2.1093 paragraph (d) (2).

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Refer to the User's Guide for general FCC statements.

Procedure to View a Product's Certification(s)

1. Go to www.us.zyxel.com
2. Select your product from the drop-down list box on the ZyXEL home page to go to that product's page.
3. Select the certification you wish to view from this page.

About Your ZyXEL G-200

The ZyXEL G-200 is an IEEE 802.11g compliant wireless USB Adapter that connects to USB ports on desktop or notebook computers. With the ZyXEL G-200, you can enjoy the wireless mobility within the coverage area. The IEEE 802.11g technology provides greater range and offers transmission rate at up to 54 Mbps. Actual speeds attained also depend on the distance from the AP, noise, etc.

1. Installation Requirements

Before installation, make sure you have a computer with the following:

- Pentium II 300MHz or above
- A minimum of 20 MB available hard disk space
- 32MB RAM (64MB Recommended)
- A CD-ROM drive
- A USB port (with USB1.0/1.1, the ZyXEL G-200 can only transmit up to 11Mbps.)
- Windows XP or 2000 Operating Systems

Windows XP Users

Wireless Zero Configuration (WZC) is a wireless configuration utility bundled with Windows XP. If you are a Windows XP user and wish to use WZC instead of the bundled ZyXEL Utility, then you can either:

Install the ZyXEL Utility and then disable it (selecting "Use Windows Zero Configuration" by first right clicking



the Z icon in the system tray)

OR

Install the driver only. In this case, you must connect the ZyXEL G-200 first.

2. ZyXEL Utility and Hardware Installation

The installation procedures are similar for all supported Windows versions. Windows XP screen shots are shown unless otherwise specified.

> **Install the ZyXEL Utility before you install the ZyXEL G-200.**

1. Insert the support CD into the CD-ROM drive on your computer. The CD automatically runs. Otherwise, locate and double-click **setup.exe** on the support CD.
2. Click **Utility** to start installation.



3. A Welcome screen displays. Click **Next.**


Welcome to the InstallShield Wizard for ZyXEL G-200v2 Utility
The InstallShield® Wizard will install ZyXEL G-200v2 Utility on your computer. To continue, click Next.
InstallShield
< Back
Next >
Cancel

4. To install ZyXEL Utility, select **Utility** and **Driver** checkbox. Click **Next** to accept the default file location or click Browse to select an alternate folder.



5. Click the **Install** button to begin the installation.


Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
< Back
Install
Cancel

6. Click **Finish** to restart the computer.


InstallShield Wizard Complete
The InstallShield Wizard has successfully installed ZyXEL G-200v2 Utility. Before you can use the program, you must restart your computer.
Yes, I want to restart my computer now.
No, I will restart my computer later.
Remove any disks from their drives, and then click Finish to complete setup.
< Back
Finish
Cancel

7. Insert your ZyXEL G-200 into an available USB port on the computer by using the provided USB cable.

8. The LEDs will turn on if the ZyXEL G-200 is properly inserted.

Never bend, force or twist the ZyXEL G-200 USB cable into the slot.

9. After you install the ZyXEL Utility and insert the ZyXEL G-200, an ZyXEL icon appears in the system tray.

10. Double click the Z icon to configure your wireless adapter.

3. Driver Installation for Windows XP

1. Insert the ZyXEL G-200 to an available USB port on the computer. The LINK LED turns on if the ZyXEL G-200 is properly inserted.
2. The **Found New Hardware Wizard** window appears. Select **Install from a list of specific location (Advanced)** and click **Next**.


Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
USB2.0 WLAN
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

3. Insert the included CD into your CD-ROM drive, select Search removable media (floppy, CD-ROM…) and then click **Next**.


Found New Hardware Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM...)
Include this location in the search:
G:\ENGLISH\WINXP\PRO\
Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< Back
Next >
Cancel

4. After the driver has been installed successfully, click **Finish** to complete the installation.

Refer to the *User's Guide* to configure the ZyXEL G-200.

4. LED Display

The following table describes the LEDs on the ZyXEL G-200.

LED	COLOR	STATUS	LEDS BEHAVIOR
PWR	Green	ON	The ZyXEL G-200 is receiving power.
		OFF	The ZyXEL G-200 is not receiving power
LINK	Green	ON	The ZyXEL G-200 is connected
		Blinking	The ZyXEL G-200 is sending or receiving data
		OFF	The ZyXEL G-200 is not sending or receiving data

5. Troubleshooting

PROBLEM	CORRECTIVE ACTION
Windows does not auto-detect the ZyXEL G-200.	Make sure the ZyXEL G-200 is properly connected via the USB slot and then restart your computer. Once the computer has restarted, check the status of the LEDs on the ZyXEL G-200.
	Perform a hardware scan by clicking **Start**, **Settings**, **Control Panel** and then double-click **Add/Remove Hardware**. (Steps may vary depending on which Windows version you use). Follow the on-screen instructions to search for the ZyXEL G-200 and install the driver.
	Check for possible hardware conflicts. In Windows, click **Start**, **Settings**, **Control Panel**, **System**, **Hardware** and then click **Device Manager**. Verify the status of the ZyXEL G-200 under **Network Adapter**. (Steps may vary depending on the Windows version).
	Install the ZyXEL G-200 in another computer. If the error persists, there may be a hardware problem. In this case, please contact ZyXEL customer support at **800-978-7222** or on the web at **http://www.us.zyxel.com**.

6. Customer Support

Please have the following information ready when you contact customer support.

- **Serial number** for your specific product
- **Warranty Information**
- **Date** that you received or purchased your device
- **Brief description** of the problem including any steps that you have taken before contacting the ZyXEL Customer Support Representative

SUPPORT E-MAIL	TELEPHONE	WEB SITE
support@zyxel.com	+1-800-978-7222	www.us.zyxel.com